


BB ving

Senter

STB ving



Aft position

PIR sensorer MÅ installers slik at de KUN dekker det aktuelle område de skal dekke.